Tenluxe Inkcleaner ® Suitability

- Tenluxe Inkcleaner® is suitable for the following industries:
 - Ball gown industry
 - Garment retailers
 - Silk and synthetic fabric industries
 - Quilting
 - Fabric inspectors
 - Bedding manufacturers and sellers
 - Garment manufacturers
 - Plastic outer shells of household appliances
 - Office workers


<u> Tenluxe Inkcleaner® is NOT suitable for:</u>

- Non-oil based stains, such as dye stains on fabric
- Serious moulding or yellowed stains that have already altered the fabric

How to Use Tenluxe Inkcleaner®:

Method 1:

We recommend the following simple steps to enable you to achieve the desired results:



1. Lightly rub or wipe the entire stained area with clean water until moistened.



2. Lightly apply Tenluxe Inkcleaner® to the stained area.



3. **For surface stains**: use a toothbrush to lightly brush off the stain;

For mid-layer stains: you can cut the thistles of the toothbrush shorter, so that greater force can be applied to the stain with the toothbrush.

For deep-layer stains: lay out the fabric flat on the workbench, and use the handle-end of the toothbrush to lightly scrub the stained area.

(Please note that the handle must be smooth, so as not to damage the fabric. Professional garment makers often use the blunt tip of the bone pen to add to the internal friction between fibers, further improving the stain-removing effect.)



4. Rinse off the stained area with water.

We suggest filling a container (such as a cup) up to 90% with clean water, place the fabric directly over the cup, and use the handle of the toothbrush to dip the fabric slightly into the water for rinsing. The residual detergent will be diluted by the water in the container (or cup).

The water in the cup should be replaced with clean water if necessary. Use a dry cloth to soak up the extra moisture in the fabric, or spray off the extra moisture with an air gun. Remember to re-cap Tenluxe Inkcleaner®, and keep the tube in a dry



place.

Alternative Ways of Using Tenluxe Inkcleaner®:

Method 2:

Rub a small amount of Tenluxe Inkcleaner® onto a dampened towel or rug, and use it to directly wipe away a surface stain. This method can be used not only with garments and fabric, but also with casings of general household appliances and electronic products. Then simply wipe with a clean, dampened cloth.

Method 3:

Directly apply Tenluxe Inkcleaner® onto the stained area of the fabric or garment, and then use the Tenluxe® Textile Spray Gun Type B-4 (for spraying water only) to spray off the stain with water. Finally, use a dry cloth to soak up any extra moisture, or spray off the extra moisture with an air gun.

Method 4:

For certain garments with transparent oil-based stains, directly apply Tenluxe Inkcleaner® onto the stained area, and then wash as usual in the washing machine.

PLEASE BE ON ALERT FOR COUNTERFEITS!

All Tenluxe® products are manufactured and sold by Tenluxe Co., Ltd. in Taiwan. We have never authorized any other company for OEM, ODM, or production by any other company in other areas or countries.

To protect your rights as consumers, please ensure that you are purchasing



Tenluxe Inkcleaner® or Tenluxe® Textile Spray Guns with our registered trademark, and please also feel comfortable in requesting for proof that the product you are purchasing is an authentic Tenluxe® product.